



---

## CHLORINE SHOCK TREATMENTS

High chlorine concentrations frequently used to shock treat bacteriological levels within industry standards will not adversely affect the performance of SBR gaskets. Exposure is for a short duration and the system is normally flushed with fresh water and placed in service after bacteriological samples pass. The gaskets will perform quite satisfactorily throughout the service of the pipe system.